


Wiring diagram




Test switch and LED indicator

LED indicator

Red stable: Charging mode

Charging Fully

OFF: Emergency mode



| Indicator Light | Status | Comment |
|--------------------------------------|------------------------------|---|
| Red Stable | Charging Mode, Fully charged | AC mode, unit is operating correctly. |
| Flashing 2 times, Light off 2s, loop | Battery Error | Battery disconnected or fail 90mins duration test due to insufficient capacity |
| Flashing 3 times, Light off 2s, loop | Charging Error | Ensure input wiring is correct and verify input voltage & frequency are correct and stable. |
| Flashing 5 times, Light off 2s, loop | Temp Error | Overtemperature |
| Continuous Flashing | LED load abnormal | Matching test fail, self-check output abnormality |

Test switch

Press switch to enter into emergency mode, release to recover charging mode

Rest mode

Rest mode can ensure battery long term storage, leakage current is very low in rest mode.

Press and hold the test switch for over 3 seconds in the emergency mode to enter into rest mode.

In rest mode, the battery is completely disconnected from the inverter, and the small leakage current can make its storage time longer.

Cancel faulty mode

End discharge

Disconnect battery in emergency mode

Press test button over 3 seconds in emergency mode.

Installation instruction:

-please install this product properly by the licensed electrician.

-please check and confirm all the data and usage surrounding before installation.

-this item could be used in the sealed fixtures or installed open area of the fixtures.

-please keep it away from the flammable materials with a place of good heat dissipation.

-please charge the battery consistently for >24 hours for the first time usage so as to activate the whole battery cells of discharging/charging duration.

WARRANTY

This product is warranted for 5 years from the date of purchase. If this product does not perform to the specifications supplied on this package, send an email to support@runbisonlighting.com for product return and replacement. This replacement is the sole remedy available. Liability for incidental or consequential damage is expressly excluded.